

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- a) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- b) This seasonal use product is not intended for permanent installation or use.
- c) Do not mount or place near gas or electric heaters, fireplace, candles or other similar sources of heat.
- d) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- e) Do not let lamps rest on the supply cord or on any wire.
- f) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- g) This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
- h) Do not use this product for other than its intended use.
- i) Do not hang ornaments or other objects from cord, wire, or light string.
- j) To avoid the risk of fire, do not leave light string on carpeting, drapes, furniture or the like while power is on.
- k) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- l) Do not cover the product with cloth, paper or any material not part of the product when in use.
- m) This product is equipped with push-in type lamps. Do not twist lamp.
- n) Do not cut or alter the light string or any component in any way.
- o) This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the User Servicing Instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded.
- p) Read and follow all instructions that are on the product or provided with the product.

REPLACEMENT:

1. Use only the bulb or fuse included
2. 3.5 volts for 35 lights string
2.5 volts for 50 or 100 lights string
3. 125v, .5 amp fuse for extension cord.

MADE IN CHINA
FOR INDOOR USE ONLY
115 - 125V.

INSTRUCTION MANUAL



INDOOR USE ONLY

115-125 VOLTS

PROFESSIONALLY TRIMED

FROM LIGHTS SET FACTORY

UL-A

PARTS INCLUDED FOR SET-UP OF YOUR TREE:


- Tree stand and 2-5 sections of tree
- Replacement bulbs: 20-100 lights---3 bulbs 105-350 lights---6 bulbs
355-650 lights--- 10 bulbs 655 light up---20 bulbs

HOW TO ASSEMBLY:

1. Before you start to assemble your tree, choose a clear, level location near a wall outlet. Open the tree stand and tighten the locking screws on the stand.
2. Carefully insert the Bottom Section of the tree into the locked stand. Make sure all wires stay clear of the stand opening when joining the sections.
3. Allow branches to fall into place or gently pull out and down. When adjusting branches be sure that all wires are free of branch hinges.
4. Locate the stacked plugs in the tree section. Plug the stack into the extension cord on the tree pole. **DO NOT Separate Any Plug From the Stack.**
5. Plug the extension cord plug into your wall outlet. The tree section should now light up. If any lights do not light, check the plug stack for loose plugs. Also, check for broken or missing bulbs. If you find broken or missing bulbs, replace with replacement bulbs, as necessary.
6. Insert the tree Middle Section into the top of the pole for the standing Bottom Section. Repeat Assembly Steps 1 through 4 for the Middle Section of the tree. Plug the plug stack into the lower extension cord outlet.
7. Insert the tree top section into the top of the pole for the middle section. Repeat Assembly steps 1 through 4. Plug the single plug for the top section into the top outlet of the extension cord located at the top of the middle section of the tree.

STORAGE:


1. Unplug the power strip from the wall outlet.
2. Unplug each section from the extension cord.
DO Not Separate Any Plug From It's Stack.
3. Gently lift off the top and middle sections and remove the bottom section from the tree stand.
4. Carefully replace the tree in its box. Store the box in a cool, dry place.



USER SERVICING INSTRUCTIONS


THIS PRODUCT EMPLOYS A REPLACEABLE FUSE. THE FOLLOWING INSTRUCTIONS SHOULD BE FOLLOWED FOR SUCCESSFUL REPLACEMENT FOR THE FUSE:

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Open fuse cover(s). Use a small blade screwdriver to slide open fuse access cover on top of attachment plug towards blades.
- c) Remove fuse(s) carefully. Turn fuse holder over to remove fuse(s).
- d) Risk of fire. Replace fuse(s) only with 3 Amp, 120 Volt fuse (Provided with product).
- e) Close fuse cover(s). Slide closed the fuse access cover on top of attachment plug.




Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. This product employs series-connected lamps. **CAUTION-TO REDUCE THE RISK OF OVERHEATING, REPLACE BURN-OUT LAMPS PROMPTLY.** The following instructions should be followed for successful replacement of the lamp(s) Reminder: Once lamp is replaced, do not twist or entire string may not light.


FOR METAL POLE TREE INSTRUCTION SHEET




1. OPEN THE TREE STAND AND TIGHTEN THE LOCKING SCREWS ON THE STAND. INSERT THE BOTTOM SECTION OF THE TREE C INTO THE LOCKED STAND. MAKE SURE ALL WIRES STAY CLEAR OF THE STAND OPENING WHEN JOINING THE SECTIONS.



2. INSERT THE MIDDLE SECTION OF THE TREE B INTO THE POLE OF BOTTOM SECTION C.



3. INSERT THE TREE TOP A INTO THE POLE OF MIDDLE SECTION B.



4. OPEN THE BRANCHES AND SHAPE THE TREE STYLE AS YOU WANT.